

# **User Manual** PeopleLink AIO DSP 200Watts

Product Manual | Edition | Release 112023 | PPU-MCC-DSP-AIO-200W



## PeopleLink AIO DSP Quick Start Guide

#### (English Version)

Please read this Manual before setting up PeopleLink AIO DSP and stick to its requirements strictly for Safety reason. Suggest you save this manual for furtherinquiries reference.



2021 PeopleLink Unified Communications Pvt. Ltd. All rights reserved. PeopleLink Unified Communications Pvt. Ltd. Q3-A3, 10th Floor, Cyber Towers, Hitech City Madhapur, Hyderabad – 500081 India

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of PeopleLink Under the law, reproducing includes translating into another language or format. As between the parties,

PeopleLink, retains title to and ownership of all proprietary rights with respect to the software contained within its products.

Therefore, you must treat the software like any other copyrighted material (e.g., a book or sound recording). Every effort has been made to ensure that the information in this manual is accurate. PeopleLink, is not responsible for printing or clerical errors. Information in this document is subject to change without notice.



## Table of Contents:

Important Safety Instructions	1
Warnings	1
User Responsibility	2
Introduction	3
Product Images	4
Connectivity Diagram	5
All in one DSP	6
Key Features	6
Applications of Multichannel Console DSP	6
Wireless Microphone System	7
Amplifier	7
Digital Signal Processor	7
Interface 8 Packaging Information	7
Miscellaneous	8
Packaging Information	8

## 🔁 PeopleLink

#### 1. Important safety instructions

Before using your AIO-DSP Series, be sure to carefully read the applicable itemsof this Operation Manual and the Safety Instructions.

- Read these instructions.
- Keep these instructions
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for longperiods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord orplug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Before you start the device kindly check Proper earth grounding to avoidelectrical interference.

## 2. Warnings

- To reduce risk of fire or electric shock, do not expose this apparatus to rain ormoisture.
- Apparatus must be connected to a mains socket outlet with a protective arthing connection.
- The mains plug is used as a disconnect device and shall remain readilyoperable.
- To prevent electric shock do not remove top or bottom covers. No user serviceable parts inside. Refer servicing to qualified service personnel.
- Check the voltage in your area and use the correct type of mains connector.
- Do not install this device in a confined space.



## 3. User responsibility

#### **Mains connection grounding**

Your amplifier must be connected to a grounded socket outlet.

#### Speaker output hazard

- In Class-D amplifier Make sure when you are going to connecting the Speakercable do not short (+)&(-) terminals
- External wiring connected to the speaker terminals shall be installed by a qualified person, or ready-made leads or cords of appropriate capacity shallbe used
- As the amplifier outputs produce respective voltage, do not connect or disconnect speaker cables when the mains power is on.

#### Maintenance

For safe and reliable operation, any dust collected in the front panel should be removed regularly. In rare circumstances, accumulated dust could ignite due tohigh internal temperatures and cause a fire. If the front is clogged so that air cannot pass, then the unit will eventually go into thermal protection; any resultant problems will not be covered by the warranty.

# **PeopleLink**<sup>®</sup>

## Introduction:

#### Welcome

- Thank you for choosing a AIO-DSP-200Watts from PeopleLink this product built around the IntelliDrive Energy Efficient Amplifier.
- Please read through this manual in its entirety to become fully acquainted with configuration options and protection circuitry.
- AIO-DSP are designed and built specifically for the unique demands of permanent installation applications into 1.5U chassis,

#### **Unpacking and visual checks**

Every AIO-DSP amplifier is carefully tested and inspected before leaving the factory and should arrive in perfect condition. If any damage is discovered, please notify the shipping carrier immediately. Save the packing materials for the carrier's inspection and for any future shipping.

#### Mounting

The AIO-DSP amplifier is one rack unit high (1.5U) and will fit into a standard 19"rack.Free airflow from front of the amplifier must be allowed

#### **Operating voltage**

The AIO-DSP Amplifiers have SMPS power supply Power Supply Safety: SwitchMode Power Supply Unit. Overload And Overvoltage Protection that accept input voltage as 230 V and 50 Hz, Once a suitable AC supply is connected, the amplifier will be start When the amplifier is turned on the below logo "power" LED becomes Blue toindicate that the amplifier is on.

#### Grounding

Always connected with 3 pin Mains cord with proper grounding to avoidbalanced input hum and interference



## **Product Images**



Front Side



Lapel Microphone

## Handheld Mic






**50W Speakers** 



**50W Speakers** 

## **Connectivity Diagram**





## PeopleLink All In One DSP 200W



PeopleLink DSP is the ultimate choice for High Definition Audio signal processor. The most powerful HD audio available, it delivers full continuous presence meetings with Multi Location Voice conferencing over its 4 inputs and 2 output DSP, ideal for local sound reinforcement. Highly scalable and flexible -PeopleLink's Multichannel Console DSP provides HD voice communications platform. This powerful, fault tolerant solution is ideal for the communication needs of large enterprises as well as Service providers looking to offer video conferencing services. Advanced design - This is the most powerful and up to date microphone Mixer, DSP and Amplifier available in the Industry today. It is Compact, Simple and extremely User-friendly allowing you to do Large scale Video Conferencing from a compact audio System.

#### **Product Features**

Range	: Wide operating range of 100 feet	
Power Supply Safety	: Power Supply Unit with Short Circuit, Overload and Over Voltage Protection	
SMT SMT Circuit	: Surface Mount Technology (SMT ) Circuit	
Efficiency	: High efficiency of ~90%	
Current	: Very low quiescent current. Can run on inverter.	
Circuit	: Technology (SMT) Circuit Integrated Self-Protection Surface Mount	
<b>Frequency lock</b>	: Quartz-locked frequency	
Area of application	: Classrooms, Training	
Rooms <b>Capacity</b>	:40 to 60 seater	
Chassis	: 19-Inch chassis 1.5U (Rack Mountable) DSP with Inbuilt amplifier	
	withwireless microphone System	

#### **Applications of Multi Channel Console DSP**

- Area of Application: Classroom, Training room, and small auditorium
- Capacity: 40 to 60 persons

## PeopleLink<sup>®</sup>

## Wireless Microphone System

Frequency type	: Quartz locked frequency
Operating Range	: 100 Feet
Microphone Options	: 2 x Handheld/ 1 Handheld +1 headband / 2 x headband Mic
Frequencies	: 5 non interfering frequencies available
Antennas	: Soft, Flexible rubberized antennas
Output LCD Display	: Balanced Phoenix and Mixed Unbalanced 1/4" Outputs : Frequency, Group, Antenna & Channel is displayed on the LCD in the receiver
Gain Control	: Separate gain controls for both the channels
Microphone Frequency Response	: 80 Hz-18KHz
Microphone Type	: UHF

## Amplifier

## **Digital Signal Processor**

Power output @ 8		Frequency Range	: 30 Hz. to 16 KHz.
ohms	: 2 X100W, Vcc= 24V DC	Automatic Echo Cancellation	:Yes
Minimum impedance	: 8 ohms @50W	Automatic Gain Control	: Yes
Frequency response	: 20 Hz-20,000Hz	Dynamic Noise Reduction	:Yes
Operating supply voltage	: 8 V to 24 V	Noise Suppression	:Yes
Туре	: Class D (Digital)	Full Duplex	: Yes

#### Interface

Input	: Built-In 1 x Handheld, 1 x Headband Microphone
Unbalanced MIC input	: 1x 6.5mm Phono jack with gain controller
Balanced 48v/12v phantom MIC inputs	: 2x Phoenix ports with separate gain controller
Line input	: 1 x 2RCA
Line Output	: 1 x 2RCA
USB Interface for PC Connectivity	: 1 x USB 2.0
RS-232 for controlling	: 1x RS-232 audio controlling



#### **Miscellaneous**

Power Supply Unit (PSU)	: Power Supply Unit with Short Circuit, Overload and Over Voltage Protection
Application	: Classrooms, Training Rooms
Capacity	: 40 to 60 Seater
Shape of the room	: Any

## **Packaging Information**

Components	: 19 inch chassis 1.5U (Rack Mountable) with Inbuilt DSP
Package Includes	: Inbuilt Package Includes PeopleLink Multi Channel Console DSP with
	built-in Amplifier, Wireless Handheld Microphone, Wireless Headband
	Microphone, USB 2.0x1, Cable, Stereo to Microphone, 2 RCA Cable x2,
	50W Speakers x2



## **Ordering Information**

#### Part code

#### : PPU-MCC-DSP-AIO-200W